

Why SkyIPCam?

- Surveillance is necessary for personal properties safety
- Accessible from anywhere that has Internet connection
- Standalone networking device that can function without any PC

How Does SkyIPCam Work?

Install SkyIPCam to your local area network, then you will be able to:

- monitor the space through SkyIPCam from any LAN computer.
- monitor the space through SkyIPCam from a 3G cellphone. (AICN777W only)
- monitor the space through SkyIPCam from a remote computer (i.e you can monitor your home environment at your office).

In order to do this, you will need to:

- Apply a Dynamic DNS address from www.dyndns.org
- Open ports on your router and link to the IPCam (You can find further instructions in the user's manual.)
- record video, trigger your alarm system, send alert E-mail by motion trigger or schedule.

A. Viewing from web browser



B. Viewing from 3G mobile phone / PDA

